

# How to update my drive?

This manual shows you how to  
update your drive.

Philips Consumer Lifestyle  
Version 02

**PHILIPS**

1 Start the Update Tool you downloaded.



2 Your drive is being updated.  
Do not interact with the system.



3 Your drive has been updated.  
Click "OK" to exit the update program  
and to restart your computer.

